



RSC Showcase Filter Cleaning Instruction

Revision: A

Date: 11/10/2014

Subject: RSC Filter Cleaning


Frequency: Clean once per week



Step 1: Remove filter every week from lower section behind the air curtain grill.

Step 2: Wash the filter with water only to remove dust and dirt. Shake the water from the filter and wipe off with a paper towel. Recommended sinks for cleaning- Mop sink as a primary recommendation, wash bay in 3-comp sink secondary option- must clean and sanitize sink before and after use.

Note: The filter does not need to be completely dry before it is placed back in the RSC Showcase.



Step 3: Dry in backroom away from food storage on clean, sanitized area.

Step 4: Replace the filters by dropping filter into the brackets by the front grill.



Note: Depending on the model of the RSC there may be multiple filters.

